


RSV 130-11      RSV 200-11  
RSV 130M-11    RSV 200M-11  
RSAV 130MF-11 RSAV 200M-11



## 960W Kit A30A

# GB




Original Instructions -  
CAUTION, Read instructions before using the machine.




[www.numatic.co.uk](http://www.numatic.co.uk)

Kit A30A




Assembly










Note\*

The remote switch cable should pass through the belt loop, making it easy to find when wearing the machine.




Using your machine





RSV 130

Start








RSV 200









Data

1	2	3	4	5	6	
Drum Size	Cleaning Range	Weight (Ready to work)	Sound Pressure (LpA) Uncertainty (KpA)	Protection Class	Dimensions	
130 200 200 MF	6 L 9 L 9 L	31.4 m	7 Kg 8 Kg 8 Kg	$\leq 70$ dB (A) 0.5 dB	Class II	250 mm x 360 mm x 440 mm 250 mm x 360 mm x 550 mm 250 mm x 360 mm x 550 mm
Voltage 220 - 240V			Motor 960W			

1	2	3	4	5	6	
Drum Size	Cleaning Range	Weight (Ready to work)	Sound Pressure (LpA) Uncertainty (KpA)	Protection Class	Dimensions	
RSAV 130 RSAV 200	6 L 9 L	43.2 m	7.37 Kg 8 Kg	$\leq 70$ dB (A) 0.5 dB	Class II	250 mm x 360 mm x 440 mm 250 mm x 360 mm x 550 mm
Voltage 110V			Motor 960W 400Hz			



## RSV 200 MF - HEPA Filter Cartridge Replacement



## About your machine

- 1 Voltage
- 2 Frequency
- 3 Rated Input Power
- 4 Weight (ready to work)
- 5 Company Name & Address
- 6 Model
- 7 Machine yr/wk Serial number
- 8 WEEE Logo
- 9 Protection Class 2 Symbol
- 10 CE Mark

### Rating Label

**Numatic International Ltd**  
CHARD, ENGLAND, TA20 2GB

\*\*\* \*\*

1 \*\*\* V  
2 \*\*\* Hz  
3 \*\*\* W

4 \*\* Kg

5  
6  
7 094709460  
8  
9  
10

**PPE** (personal protective equipment) That may be required for certain operations.

Ear Protection	Safety Footwear	Head Protection	Safety Gloves	
Eye Protection	Protective Clothing	Dust / Allergens Protection	Hi Viz Jacket	
				Caution Floor Sign

NOTE: A risk assessment should be conducted to determine which PPE should be worn.

### WEEE Legislation (Waste, Electrical and Electronic Equipment)

Vacuum cleaner, accessories and packaging should be sorted for environmentally - friendly recycling.

(Only for EU Countries) Do not dispose of vacuum cleaner into household waste! According to the European Directive 2012/19/EU on waste electrical and electronic equipment and its incorporation into national law.

Vacuum cleaners that are no longer suitable for use must be separately collected and sent for recovery in an environmentally - friendly manner.



Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or the Numatic Technical helpline +44 (0)1460 269268

#### Daily

Keep the machine clean, including hoses and tubes.  
Ensure the bag and filter are fitted.  
Regularly examine the power cord.  
Check dust bag frequently.  
Check filters are clean.

#### Weekly - as daily and:-

Check for any worn or damaged parts and replace immediately.

MAINTENANCE

### Safety Critical Components

Mains leads:

HO5-VV-F 12.5 m x 2 Core x 1.00 mm<sup>2</sup>

**GB**

## Information for DRY use Vacuum cleaners

### WARNING

*Read the instruction manual before using the machine.*

*Operators shall be adequately instructed on the use of their machine.*

*As with all electrical equipment, care and attention must be exercised at all times during use, in addition to ensuring that routine and preventative maintenance is carried out periodically to ensure safe operation.*

*Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility in this respect.*

*Maintenance should only be carried out by a qualified person.*

*This machine is for DRY USE only and must not be stored outside or used in wet conditions.*

*The machine shall be disconnected from the mains by removing the plug from the supply socket during cleaning or maintenance and when replacing parts or converting the machine to another function.*

*This machine is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience or knowledge.*

*This appliance is intended to be cleaned and maintained by an adult.*

*Children being supervised are not to play with the machine.*

*This machine is not a toy.*

*This machine is not suitable for picking up hazardous or explosive dust.*

*Contact your local distributor if you require a machine capable of performing these tasks.*

### CAUTION

*Ensure that the filtration system fitted to the machine is suitable for the material being collected.*

*This vacuum cleaner is intended for indoor use in the collection of dry materials.*

*This machine should be stored indoors only.*

### NOTES

*The primary use for this machine is commercial, for example in hotels, schools, hospitals, factories, shops and offices.*

*This product complies with the requirements of clause 20 of IEC/EN 60335-2-69 Stability and Mechanical Hazards.*

*This vacuum cleaner is fitted with a thermal protection device. If the vacuum cleaner stops working, remove the plug from the wall before investigating where the fault lies.*

*If the vacuum cleaner has a blockage, switch off, remove the plug from the socket, inspect the floor tool, tubes and hose for debris. If the floor tool, tubes and hose are clear, replace the dust bag and clean the filter.*

*The vacuum cleaner should be inspected after use for damage.*

*The vacuum cleaner should be stored in a dry place.*

*When moving from one place to another, consider the weight of the machine.*

### DO

- *Keep your machine clean including hoses and tubes.*
- *Change dust bag frequently.*
- *Keep filters clean.*
- *Keep diffuser filter (where fitted) clean.*
- *Use filter bags, they will enhance performance and help keep machine clean.*
- *Use a Numatic Original filter bag under fine dust conditions.*
- *Keep hoses and tubes clear.*
- *Replace any worn or damaged parts immediately.*
- *Only use the socket outlet on the machine for purposes specified in the instructions.*
- *Only use the brushes provided with the machine. The use of other brushes may impair safety.*
- *Regularly examine the power cord. If damage is found such as cracking or ageing the power cord must be replaced by a qualified person.*
- *Only replace the power cord with the correct Numatic approved replacement part.*


### DO NOT

- *Pull on the cable to unplug the machine from the power supply.*
- *Use to suck up hot ashes or lighted cigarette ends.*
- *Use steam cleaners or pressure washers to clean the machine or use in the rain.*
- *Immerse in water for cleaning.*
- *Attempt machine maintenance or cleaning unless the power supply plug has been removed from the supply outlet.*
- *Use in wet environments or to collect wet materials.*
- *Under any circumstances place foreign objects including (but not limited to) air fresheners, air freshener capsules or scented beads of any type into the top filter of the machine. Doing so can be dangerous and risk damage to the machine and may invalidate the machine warranty.*


Schematic Diagram

RSAV / RSV 200

RSAV 200 WD-0361 120V 800W




RSV 200 WD-0280




RSAV / RSV 130


RSAV 130 (DRW 19453) 120V 800W




RSV 130 (DRW-13363) 230V 620W



RSV 130 (DRW 20715) 120V 800W



RSV 130 (DRW-13365) 120V 900W



Replacement parts

TriTex Filter	
604168	TriTex Filter
HepaFlo Dust Bags	
604011	130 Drum - HepaFlo Dust Bags (Pack of 10) NVM-1AH
604015	200 Drum - HepaFlo Dust Bags (Pack of 10) NVM-1CH
For best performance make sure you use genuine Numatic bags	

# Numatic International Warranty

Numatic International Limited warrant to the original purchaser that its products are free of defects in both material or workmanship for the period shown below:-

<b>Homecare and Cleancare Vacuum cleaners.....</b>	<b>2 Years</b>
<b>Rotary Floor Machines.....</b>	<b>2 Years</b>
<b>Twintec Auto Scrubber Dryer.....</b>	<b>1 Year</b>
<b>Mopping, Compacts, Combi and Servocare Products.....</b>	<b>1 Year</b>
<b>Individual Accessories and Spare Parts.....</b>	<b>6 Months</b>

Note: This warranty expressly excludes consumable parts such as carbon brushes, floor brushes, mops, batteries etc, that are considered replaceable from time to time during the normal working life of the machine.

Using non Numatic dustbags can be detrimental to both machine performance and life and may invalidate the Warranty.

A. The warranty period commences from the date the goods are purchased.

B. All warranty claims must be processed through the Dealer from whom the equipment was purchased. The Dealer will co-operate with the purchaser throughout the warranty claims procedure and will arrange any necessary repairs using genuine Numatic parts.

C. If the original Dealer is no longer able to fulfil his obligations please contact Numatic International Limited with full details of the claim and proof of purchase so that this may be processed without delay.

D. Any warranty claim can only relate to the specific part that is proven to be at fault and for which a replacement will be supplied but cannot be extended to constitute a claim against the complete machine.

E. Numatic International will supply the Dealer with any warranty parts required, subject to the claim being validated, after return of the faulty items in accordance with Numatic International Limited's General Conditions of Sale.

F. Claims will not be accepted if they are the result of fair wear and tear, misuse or abuse of any kind.

G. No replacement will be given unless the appropriate evidence of the validity of the claim has been provided to the satisfaction of Numatic International Limited.

H. Numatic International Limited reserve the right to charge for any unnecessary work carried out as a result of an invalid claim.

I. No variation to this warranty may be made or implied by any member of Numatic International Limited or its Dealers unless such variation is in writing and authorised by the Company.



**Numatic International Limited. Chard, Somerset, TA20 2GB**

**Telephone: 01460 68600 Fax: 01460 68458**

**© Numatic International Limited 2017**



**EU DECLARATION  
OF  
CONFORMITY**

We hereby declare under our sole responsibility that the following equipment fulfils all the relevant provisions of the following EU Directives:

Machinery Directive 2006/42/EC

EMC Directive 2014/30/EU

RoHS Directive 2011/65/EU

**Machine Description: Vacuum Cleaner**  
**Type: RSV, RSAV series**

**Manufactured by: Numatic International Limited**

Relevant standards upon which conformity is declared include:

IEC 60335-1: 2010

IEC 60335- 2-2: 2009

IEC 60335-2.69: 2002 +A1 +A2

EN 55014-1 2001 +A1 2001, +A2 2002

EN 55014-2 1997 + A1 2001 (Cat II)

EN 50366 2003 + A1 2006

A technical construction file for this equipment is retained at the manufacturer's address under the authorisation of the following signatory:

**Name: Allyn Boyes**

**Position: Technical Manager**


Signed:

Date: 20/04/2016




Numatic International Limited,  
Chard, Somerset.  
TA20 2GB  
[www.numatic.co.uk](http://www.numatic.co.uk)


**GB**



Numatic International Limited.  
Chard, Somerset TA20 2GB ENGLAND  
Tel: 01460 68600 [www.numatic.co.uk](http://www.numatic.co.uk)




Numatic International GmbH. Fränkische Straße 15–19  
D-30455 Hannover, DEUTSCHLAND  
Tel: 05 11 98 42 16 0 [www.numatic.de](http://www.numatic.de)



Numatic International SAS. 13 / 17 rue du Valengelier  
77500 CHELLES, FRANCE  
Tel: 01 64 72 61 61 [www.numatic.fr](http://www.numatic.fr)



BeNeLux Distribution, Numatic International BV  
Postbus 101, 2400 AC Alphen aan den Rijn, NEDERLAND  
Tel: 0172 467 999 [www.numatic.nl](http://www.numatic.nl)



Numatic International (Pty.) Ltd.  
16th & Pharmaceutical Roads, Midrand, Gauteng,  
SOUTH AFRICA 1685  
Tel: 0861 686 284 [www.numatic.co.za](http://www.numatic.co.za)



Numatic International Schweiz AG.  
Sihlbruggstrasse 142, 6340 Baar. SCHWEIZ  
Tel: 0041 (0) 41 76 80 76 - 0 [www.numatic.ch](http://www.numatic.ch)



Numatic International ULDA. Centro de Negócios da Maia,  
Rua Albino José Domingues, 581, 4470 – 034 Maia PORTUGAL  
Tel: +351 220 047 700 [www.numatic.pt](http://www.numatic.pt)



Numatic International SLU. C/ La Forja, 41, 08840 Viladecans  
(Barcelona), Spain  
Tel: +34 93 647 22 22 [www.numatic.es](http://www.numatic.es)

Specification subject to change without prior notice  
[www.numatic.co.uk](http://www.numatic.co.uk) © Numatic International Limited